

Step 1: Unbox the balloon.



Step 2: Remove the battery pack, remote control and plastic cord out of the basket.




Step 3: Place battery (not included - CR2025) in the remote control (Fig A).




Step 4: Add AA penlite batteries to the battery pack.
(Number of batteries depending on size battery pack. 2 pcs for the Balloons Travel Light (Fig. B.1), 3 pcs for the Balloons Royal Aero and Jules Verne (Fig. B.2).)




Step 5: Switch battery pack to ON.
Place battery pack in balloon basket and then make sure the cable goes through the center circle toward the LED Socket.



Step 6: Put the plug into the LED Socket (Fig. C).
Make sure you push-in firmly.



Step 7: Put the cord through the loop on top of the balloon (Fig. D) and hang the balloon with the cord.
The balloon can be switched on and off by using the remote control.



REPLACE THE BATTERIES:

- Step 1:** Remove the plug from the LED Socket. Always keep one finger on the LED Socket as seen on Fig E. to prevent the LED socket from being pulled out
- Step 2:** Remove the battery pack and replace the batteries.
- Step 3:** Repeat step 5 till 7 of the instructions

IMPORTANT: LED socket can be pulled out for replacement and is therefore not permanently fixed to the balloon.



Fig E.

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **Keep** new and used batteries **OUT OF REACH of CHILDREN**.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children.

Do NOT dispose of batteries in household trash or incinerate.

Even used batteries may cause severe injury or death.

Call a local poison control center for treatment information.

This product contains a type CR2025 battery.

The nominal battery voltage is 3V.

Non-rechargeable batteries are not to be recharged.

Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate.

Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

Ensure the batteries are installed correctly according to polarity (+ and -).

Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

Always completely secure the battery compartment.

If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.



This icon refers to: Ingestion hazard, this product contains button batteries or coin batteries.